

Phoenix 8610, 8611, 8612 Gasket Replacement

Kit #96-58601

Date: 1/8/2003 Page: 1

GASKET KIT CONTENTS:

5 - Ft 3/8" Medium Density Rope Gasket

5 - Ft ³/₄" Tape Gasket

3 - Ft 3/8" Low Density Rope Gasket - pt# 3110-057

Gasket Glue

TOOLS REQUIRED:

BEFORE YOU BEGIN:

Scissors Work on a cool stove

Steel Wool or Wire Brush Phillips Screw Driver

PROCEDURE FOR DOOR GASKET REPLACEMENT

- Remove the door by lifting it straight up off the hinges. Place it face down (Use soft surface for enameled doors).
- 2. Pull out used gasket from channel and discard. Clean gasket channel using steel wool or wire brush; remove any residue. Wipe clean with damp rag or cloth.
- 3. Using the liquid gasket adhesive, apply a thin bead of the adhesive to the gasket channel.
- 4. When the adhesive becomes "tacky", apply the new 3/8" medium density gasket by pushing it into the channel.
 - Take care not to stretch or bunch the gasket.
 - Do not start in a corner; it will be more easily pulled out.
 - Cut off any excess with the scissors.
- 5. The door should be returned to the stove A.S.A.P. and shut tight to assure a positive seal.
- 6. Repeat with ash pan door using the 3/8" Low Density Rope Gasket.

PROCEDURE FOR WINDOW GASKET REPLACEMENT

- 1. Remove the door by lifting it straight up off the hinges. Place it face down (Use soft surface for enameled doors).
- 2. With the phillips screwdriver, remove the screws holding the glass clips in place.
- 3. Carefully lift the glass from the door.
- 4. Apply the new gasket to the current or new glass by wrapping the tape around the outside edge of the glass, overlapping both sides of the glass.
- 5. Carefully place the gasketed glass onto the door.
- 6. Screw the glass clips back on the door.
- 7. Install the door.